


DL 2101T33



Pulsante di emergenza

Pulsante di emergenza rosso con 1 contatto di commutazione.

Emergency Pushbutton

Red emergency push-button with 1 switching contact.

Pulsador de emergencia

Pulsador rojo de emergencia con 1 contacto de conmutación.

Bouton-poussoir d'urgence

Bouton-poussoir d'urgence rouge avec 1 contact de commutation.