



ASSEMBLY AND MAINTENANCE OF A SCREW PUMP



DL PSM04

This mounting kit allows the assembly and maintenance of a screw pump using fluids other than water and usually used in lubrication with oils.

Thanks to the cutting, the students can learn all the components of the pump and its operation.

The material is supplied stored and protected in a transport box together with the tools necessary for its use.

The user manual, supplied with the equipment, shows clearly and with many images, the entire process to follow for operating the equipment.

TRAINING OBJECTIVES

The practice's manual contains the necessary instructions for assembly and disassembly of the device, as well as necessary guidelines for carrying out its maintenance and repair.

CHARACTERISTICS

- Volumetric flow: 10 ÷ 42 l/min,
- Maximum pressure: 7 bar,
- Application: circulation, lubrication, and transfer.